


Genesis 46 Helpful Tips

This page contains useful information to help you enjoy your new truck. Please read and understand all of the following information before attempting to start your engine.

Pull Starter Tips

Do not pull the cord more than 12" out.



Correct way to pull



Wrong way to pull


Make sure you pull the cord out to the side and not up. Pulling the cord up like shown in the picture on the right will cause the cord to snap.

*** You may want to loosen the glow plug slightly to reduce the compression of the engine. This will make it easier for you to pull the cord. Once the engine has started, tighten down the glow plug. After the engine is broken in you will not need to do this anymore.**

Glow Plugs

You should periodically check the condition of the glow plug. Glow plugs may be damaged from a number of things including, leaving the glow heater on too long, running the engine out of fuel when revved up, and even just sitting around and not being used.

First take the glow plug out and look at the coil. The coil should not look burnt or bent up. Next take the glow plug and put into your glow heater as shown below. You should see the coil glow bright orange. **Be careful not to touch the coil. It may burn your finger.**



Don't burn your fingers.